

Thyristor Power Regulator TPR-3SL-EP

INSTRUCTION MANUAL

Thank you for purchasing Hanyoung Nux products. Please read the instruction manual carefully before using this product, and use the product correctly. Also, please keep this manual where you can view it any time.

HANYOUNG NUX

HANYOUNGNUX CO.,LTD
28, Gilpa-ro 71beon-gil,
Michuhol-gu, Incheon, Korea
TEL : +82-32-876-4697
http://www.hynux.com

MB0602KE190514

Safety information

Please read the safety information carefully before the use, and use the product correctly. The alerts declared in the manual are classified into Danger, Warning and Caution according to their importance

DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury
WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury
CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor injury or property damage

DANGER

To prevent electric shock while it is running, put to earth with the fixed screw of the unit and do not touch the heat sink since it is very hot. Do not touch or contact the input/output terminals because they cause electric shock.

WARNING

- If there is a possibility that a malfunction or abnormality of this product may lead to a serious accident, install an appropriate protection circuit on the outside.
- Any use of the product other than those specified by the manufacturer may result in personal injury or property damage.
- Since this product is not designed as a safety device if it is used with systems, machines and equipment that could lead to a risk of life or property damage, please implement safety devices and protections for both lives and the applications and plan for preventing accidents.
- Please supply the rated power voltage, in order to prevent product breakdowns or malfunctions.
- To prevent electric shocks and malfunctions, do not supply the power until the wiring is completed.
- Never disassemble, modify, process, improve or repair this product, as it may cause abnormal operations, electric shocks or fires.
- Please disassemble the product after turning OFF the power. Failure to do so may result in electric shocks, product abnormal operations or malfunctions.

CAUTION

- Since the product operating environment influences the product performance and expected life span, please avoid using in the following places.
 - a place where humidity is high and air flow is inappropriate.
 - a place where dust or impurity accumulates, ambient temperature is high and vibration level is high.
 - a place where corrosive gases (such as harmful gases, ammonia, etc.) and flammable gases occur.
 - a place where there is direct vibration and a large physical impact to the product.
 - a place where there is water, oil, chemicals, steam, dust, salt, iron or others (Contamination class 1 or 2).
 - a place where excessive amounts of inductive interference and electrostatic and magnetic noise occur.
 - a place where heat accumulation occurs due to direct sunlight or radiant heat.
- Please do not wipe the product with organic solvents such as alcohol, benzene, etc. (use neutral detergents).
- When water enters, short circuit or fire may occur, so please inspect the product carefully.
- Please connect the product and other units after turning off all the power of the product, instruments and units.
- Please make sure that the thyristor power regulator (TPR) is installed vertically.
- Please install the product inside of the control panel and install an exhaust fan onto the top of the control panel.
- Pay attention to the edge of heat sink which is sharp.
- Please close the cover after installation in the place in which there is a cover.
- The external circuit connected with the product should be connected by an insulated circuit more than basic insulation.
- The temperature of the body and the heat sink may be extremely high when electric current is applied, which may cause burns.

Suffix code

Model	Code	Content
TPR-2SL	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	Slim type Single phase power regulator
Rated current	040	40 A
	055	55 A
	070	70 A
	090	90 A
	130	130 A
Power supply voltage	L	100 - 240 VAC (Low)
	H	100 - 440 VAC (High)
Option	EP	Each phase control (3 device individual control)


- * The circuit power and fan power must be applied separately 100 - 240 VAC
- * 130 A, 160 A products are FAN power 24 VDC Voltage must be applied.

Specification


Model	Low	TPR-3SL 040L-EP	TPR-3SL 055L-EP	TPR-3SL 070L-EP	TPR-3SL 090L-EP	TPR-3SL 130L-EP	TPR-3SL 160L-EP
	High	TPR-3SL 040H-EP	TPR-3SL 055H-EP	TPR-3SL 070H-EP	TPR-3SL 090H-EP	TPR-3SL 130H-EP	TPR-3SL 160H-EP
Power supply voltage	Low	100 - 240 VAC					
	High	100 - 440 VAC					
Circuit input power		100 - 240 VAC 18 W					
Power frequency		50/60 Hz (Dual usage)					
Rated current		40 A	55 A	70 A	90 A	130 A	160 A
Applying load		Resistive load					
Current input		4 - 20 mA DC (Impedance : 100 Ω)					
Control method		Phase control, Fixed Cycle control, Variable Cycle control					
Movement type		SOFT START, SOFT UP/DOWN					
Output voltage		More than 98 % of the power supply voltage (In case of maximum current input)					
Cooling method		Forced cooling					
Display method		Display by LED					
Insulation resistance		Min 100 MQ (Base on 500 VDC mega)					
Output control range		0 ~ 100 %					
Dielectric strength		3000 VAC 50/60 Hz for 1 min					
Line noise		Noise by noise simulator (2,500 V)					
Ambient temperature & Humidity		0 ~ 40 °C(Without Condensation), 30 ~ 85 % RH					
Storage temperature		-25 ~ 70 °C					
Approval		CE					
Weight(g)		4,324	9,194	9,288			

Connection diagram

Connection diagram of input signal and power terminal



• Extra input power supply (For circuit power and FAX operation power) : 100 - 240 VAC (13, 14)
Have to connect power to operate unit (Even if do not need to use FAN).



• Extra input power supply (For circuit power) : 13, 14
• FAN-driven power source : 15, 16

- Inside of TPR, the fuse is installed in the R,S,T input power supply portion depending on the specification of options
- When connecting terminals, please use crimp connectors and securely fasten them due to the high current flow. (Max space for solder less terminal connection is 40/55/70 A : 16 mm, 90/130 A : 26 mm)
- Only one channel can be used per temperature controller. (Serial connection disabled)
- Since the internal GND is not separated, use a module or temperature controller that has separate analog inputs for each channel.


Connection diagram of signal and alarm terminal




- NO. 1, 2 : RS485 Communication connection port
- NO. 3, 4 : Channel 1 4 - 20 mA DC input
- NO. 5, 6 : Channel 2 4 - 20 mA DC input
- NO. 7, 8 : Channel 3 4 - 20 mA DC input
- NO. 9, 10 : Alarm1 caution
- "caution" The alarm is not a serious problem, but it is an alarm that needs to be checked by the user due to abnormal symptoms. At this time, the TPR output will go out to normal and only the alarm will be output.
- Caution error : partial load disconnection, heat sink overheat (60 °C), overcurrent, power failure, fuse disconnection, FAN error
- NO. 11, 12 : Alarm2 warning
- If a "Warning" alarm can cause damage to the product and the load, a warning will be issued in the following emergency situations. At this time, the TPR will stop the output itself.
- Warning error : Heat sink overheat (80 °C), SCR conduction (Short)
- When the input power (100 - 240 VAC) is applied, the alarm relay opens and it is shorted when an alarm occurs. ("B" contact Normal close) In case of using "A" contact
- If an alarm condition occurs, an alarm is output after 3 seconds, and if the alarm condition is released within 3 seconds, an alarm No output.

Installation panel cutout (Unit : mm)



40/55/70 A



90 A



130/160 A



LED indicator and explanation

LED indicator name	Description
POWER	POWER indicator is ON when the power is being supplied to the control unit
CH1	Lights up when an alarm related to channel 1 occurs.
CH2	Lights up when an alarm related to channel 2 occurs.
CH3	Lights up when an alarm related to channel 3 occurs.
LL	<ul style="list-style-type: none"> When the heater is configured in parallel with the partial heater disconnection function, at least one of them is disconnected. This function is to maintain the process while detecting the heater disconnection. Detectable when using less than 3 parallel heaters. (In case of 4 or more parallel configurations) The total load capacity is not detected within the range of less than 6A and 0 to 20%. Part heater disconnection detection operation method (scan function) - Corresponds to phase control, variable cycle control - After circuit and load power supply is turned on, the LL LED flashes 0 to 100% The heater value is detected while sequentially outputting the output. - If the initial scan function is used only once after connecting the heater, the value stored in the internal CPU Therefore, no further operation is required in the future. - If you do not use the scan function and leave the initial mode 2 ON, Partial heater disconnection function is activated. It is not precise in the way that it is detected by calculation formula automatically.
OT	<ul style="list-style-type: none"> The LED flashes when the heat sink temperature rises above 60 °C during control, Operation is normal, and if the heatsink temperature drops below about 50 °C Will be released. If the heat sink temperature rises above 80 °C during control, the LED will light up and TPR output will stop.
O.C	<ul style="list-style-type: none"> When an overcurrent occurs, it will light up if a current above a set value is generated to protect the product and load, Operation stop (can be set by communication) • FAN failure: Flashing when FAN fails
EMG	<ul style="list-style-type: none"> EMG LED lighting situation is as follows. 1. Power failure: The load power is turned on when the circuit power (100 - 240 VAC) is applied Lights when the heater is disconnected. 2. SCR short: When SCR is shorted, the power is on without control input and TPR output Since the heater continues to overheat, the current continues to flow without the control input. The EMG LED flashes when it flows. (10 A or more)


Internal dip switch operation

Number	OFF	ON	Initial setup MODE
No. 1	-	RESET (Functioning stops)	OFF ON <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
No. 2	load volume scan	Partial load disconnection function	
No. 3	Not Using	Restart mode	
No. 4	-	cycle control fixed cycle method	
No. 5	-	cycle control variable cycle method	
No. 4, 5	-	Phase control	
No. 6	Not Using	-	
No. 7	3 channel function fixed	use all 1, 2, 3 channels	
No. 8	-	4 - 20 mA DC	1. Input mode : 4 - 20 mA DC
No. 7, 8	Check 8 LED lights	-	2. Control Mode: Phase control


* The reset operates after turning off the switch 1 and turning it on again through the CPU reset

Function descriptions

Phase control




Fixed cycle control



As setting the constant cycle of the output, fixed cycle control is to control the AC power supply repeatedly with a constant rate of ON/OFF according to the control input.

Variable cycle control



Without setting a constant cycle, variable cycle control is to control AC power supply with using the number of cycle.

Restart function

When a warning or caution alarm occurs, TPR gives alarm 1 or 2 or stop the output. This function is used to return to normal operation mode when factors caused errors are eliminated. This function is able to set up when Fuse/Power Supply is in disorder, Heat sink over heat, SCR Short is occurred. (When Overcurrent is occurred, this function is not working)

VR Explanation

- O.C (overcurrent setting function)
When overcurrent occurs, protection function for TPR and load (Only phase control)
- The overcurrent setting can be different depending on the types of load or VR tolerance.
- In order to set an accurate position of the overcurrent setting, adjust the control signal that TPR can have the current that needs to be alarmed. Turn the O.C VR until the O.C indicator is ON. The position of the O.C VR is the overcurrent setting value.
- If OC VR turning to the right of the maximum, overcurrent function does not work.

SOFT



- This volume is to set time for Soft start or Soft up/down.
- Soft start : Protection functions against big load of start current (inrush current). It increases output softly. When control input is applied and power is on, Soft start operates when rung signal is applied. In case of maximum VR, it set 60 second. (Example : 20 mA : 60 sec, 12 mA : 30 sec)
- Soft up / down : When rung signal and power are applied and if control input is applied, it will operate. It case of maximum VR, it set 15 second.
- If VR turn up to the right, the function does not work. And if VR turn right, time will be reduced.

POWER (output limit function)

This function is to limit the output regardless of the control input amount. Even though the control input is 100 %, the output will decrease as turning POWER volume counterclockwise.

Installation

- Please install it perpendicularly. If the product is installed vertically in unavoidable circumstances, please use 50% of rated current.
- When multiple products are closely installed, please install them with keeping a distance of more than a width of 5cm and a length of 10cm as shown in the picture.
- In order to not block the air flow, please install the wiring duct less than the half of the heat sink height.
- Please consider whether the air flow is good enough when installing the product. If the ambient temperature is as low as possible in the inside then the life span of the product is increasing as the durability and reliability of the product are improving. The operating ambient temperature is 0 ~ 40°C. The maximum load current is decreasing like the below.
- When connecting R and U, please securely fasten them with using crimp connectors since high current flows into these terminals. If the contact surface of the connectors and terminals are poor, it may lead to a fire since the wires and terminal gets overheated.
- Before applying power, this model need more than the third class grounding to prevent electric shock. This model does not have separate grounding terminal so we suggest using grounding terminal and bracket together when install this model to a panel.
- Tighten the screws of the terminal block with the specified torque.
M3.5: 0.6 ~ 1.2 N.m / M6: 4.41 ~ 4.9 N.m / M8: 8.82 ~ 9.80 N.m




Communication

- Communication method: RS485 2-wire half duplex
- Communication speed: 2400, 4800, 9600, 19200 bps
- Maximum number of connections: 31
- Protocol: ModBus RTU, ModBus ASCII

Address (ID) setting



- Set the ID with DIP S/W no. 1-5
- Set 1 ~ 31 (except 0).
- When communication setting is changed, the change is applied after reset.



Communication setting (ModBus RTU/ASCII)

Communication settings				Structure (RTU)					
Communication speed	2400, 4800, 9600, 19200	bps.		Division	Address (ID)	Function	Start Address	No. of Data	CRC
Protocol	ModBus RTU	ModBus ASCII		Request	1	1	2	2	2
Parity bit	Even	None	bit	Division	Address (ID)	Function	No. of Data	Data	CRC
Data bit	8	7	bit	Request	1	1	1	2	2
Stop bit	1		bit						
ID	1 ~ 31								

Example (RTU)					Structure (ASCII)									
Division	Address (ID)	Function	Start Address	No. of Data	CRC	Division	Address (ID)	Function	Start Address	No. of Data	LRC			
Request	0x01	0x03	0x00	0x01	0x00	0x01	0x05	0xCA	Request	2	2	4	4	2
Response	0x01	0x03	0x02	0x00	0x00	0x08	0x44		Response	2	2	2	4	2



Example (ASCII)										Protocol		
Division	Address (ID)	Function	Start Address	No. of Data	LRC	END					MODBUS RTU	MODBUS ASCII
Request	0x01	0x31	0x03	0x30	0x30	0x30	0x30	0x30	0x30	0x30	2400, 4800, 9600, 19200 bps	
Response	0x30	0x31	0x30	0x33	0x30	0x30	0x30	0x30	0x30	0x30		Parity Even None
											Data bit 8	7
											Stop bit 1	1
											ID	1 ~ 31

BOLD : RAM DATA

READ	monitoring
READ/WRITE	Configurable

Communication MAP			Explanation by address					
ADDRESS	PROCESS	INFO	CAL	Process (0 ~ 99)				
Address	0	100	200	Address	Parameter	Explanation	Setting range	Unit
0	-	System	Scan Start	1	AlarmStatus	Alarm status information	Refer to Bit Information	
1	AlarmStatus	-	Scan Out Mode	2	CH1 Status	CH1 Status information	Refer to Bit Information	
2	CH1 Status	-	CH1 Complete	3	CH2 Status	CH2 Status information	Refer to Bit Information	
3	CH2 Status	-	-	4	CH3 Status	CH3 Status information	Refer to Bit Information	
4	CH3 Status	-	CH1 LL Rate	5	-	-	-	-
5	-	-	CH2 Complete	6	Soft Time	Soft start Setting time	0 ~ 60	sec
6	Soft Time	Out Mode	-	7	-	-	-	-
7	-	-	CH2 LL Rate	8	CH1 Output	SCR CH1 Yield	0 ~ 100	%
8	CH1 Output	-	CH3 Complete	9	CH1 Current	SCR CH1 Load current value	0 ~ CT (max)	(x10) A
9	CH1 Current	-	-	10	CH1 Output	SCR CH2 Yield	0 ~ 100	%
10	CH2 Output	LL Use Mode	CH3 LL Rate	11	CH1 Current	SCR CH2 Load current value	0 ~ CT (max)	(x10) A
11	CH2 Current	Protocol	-	12	CH1 Output	SCR CH2 Yield	0 ~ 100	%
12	CH3 Current	BPS	-	13	CH1 Current	SCR CH2 Load current value	0 ~ CT (max)	(x10) A
13	CH3 Current	Parity	-	14	CH1 Input	CH1 4 - 20 mA Control signal input	0 ~ 100	%
14	CH1 Input	Stop Bit	-	15	CH2 Input	CH2 4 - 20 mA Control signal input	0 ~ 100	%
15	CH2 Input	Data Length	-	16	CH3 Input	CH3 4 - 20 mA Control signal input	0 ~ 100	%
16	CH2 Input	Address	-					
17	-	R.Time	-					
18	-	CH1 Enable	-					
19	-	CH2 Enable	-					
20	-	CH3 Enable	-					
21	-	CH1 Power Limit	-					